

## **ECMLink 1G Cable Installation**

1. Locate the diagnostic connector and fuse box next to where the driver's left leg would normally rest.
2. Remove the diagnostic connector cover. The diagnostic connector cover is just a plastic boot. Remove this by pulling from left to right.
3. Once the boot is removed from the diagnostic connector, you can plug the 1G data cable into place.

