


Chip Removal Instructions – Start Here

Chip orientation:

1. Open case by removing four black screws.
2. Inside case, note chip orientation as shown in the illustration below. The new chip will have to be installed in the same direction. It **can** be installed backwards, so please observe the proper orientation.



Chip removal:

1. If you have a chip extractor tool, great. If you really want one, stop by Radio Shack and pick one up. Otherwise, grab a butter knife. A flat head screw driver also works nicely.
2. Slowly work the tip under the EPROM.
3. Apply counter pressure with your fingers on top of the EPROM to prevent sudden chip removal and bent pins.
4. Slowly twist (rotate) the knife or screwdriver from one side to the other while under the chip and continue to insert further underneath.
5. If you can come at the EPROM from the other direction as well, swapping directions a couple times, this will further reduce the chance of bending pins. But the case screw tab tends to get in the way.
6. Once the chip has been removed, install the new V2 chip in the same direction as the chip that was just removed. Running a fingernail along the outside of the pins can sometimes help to align the pins with the holes in the socket before you apply pressure.

